



FLEXI 2R (USB-C)

10.01.171.XY/USB-C X: 4 8 Y: 1 2 8



FLEXI 2R

10.01.171.XY X: 4 8 Y: 1 2 8

